ANTI-BACTERIAL/FUNGICIDE

HOSPITAL DISINFECTANT

MOLD & MILDEW CLEANER

Kills 99.9% of Germs • Kills Bacteria in 60 seconds

SNIPER® is an easy to use all-ourpose and multi surface cleaner. Hospital Disinfectant, and HEAVY DUTY Odor Eliminator with no harsh chemical fumes or residue left behind. SNIPER® has the unique ability to eliminate VOCs. SNIPER® provides this unique disinfectant and cleaning technology that is ideal for your indoor use both in homes and any institutional setting. SNiPER® technology is a versatile cleaner and disinfectant that is non-abrasive and non-corrosive with a ready-to-use, no-fragrance added formula that does not require rinsing.

Disinfect Hard Non-Porous Surfaces: For disinfection of pre-cleaned hard non-porous surfaces such as plastic, painted or finished wood, chrome, stainless steel, aluminum, galvanized coated surfaces, polyurethane coated hardwood floors, glazed ceramic tile, sealed concrete and linoleum floors, etc.

For Disinfection: Spray SNiPER® at full strength, at a distance of 6-8 inches from surfaces while wetting surfaces thoroughly. Allow surfaces to remain wet for 5 minutes for disinfection of bacteria, including: Staph and Salmonella. Allow surfaces to remain wet for 10 minutes for virus inactivation of Influenza and Canine Parvovirus (Peel back label to learn more*)

Hard Surface Sanitization: SNiPER®sanitizes hard, non-porous food contact surfaces in 60 seconds - No rinse required (Peel Back label to see Sanitization Directions for use*)

Disaster Recovery: SNiPER[®] can be used in all disaster recovery, such as fire and smoke damage or flood and water damage. Antimicrohial Eliminate Bacteria Causing Odor Fundicide (Peel back label to see fundus treatment directions for use*) Fundistat Mold and Mildew Cleaner Removes Odors from Mold / Mildew Allergen Remover (Peel Back Label to see Disaster Recovery Directions of Use*)

SNIPER® Eliminates VOC Odors: SNIPER® has the unique ability to eliminate VOC odors in the air: Ammonia • Sulfur Formaldehvde







Disinfectant Technology

ACTIVE INGREDIENTS

| Chlorine Dioxide | 0.200% | VIIIO |
|---------------------------------------|-----------------|-------------------------|
| n-Alkyl (60% C14, 30% C16, 5% C12, 5% | % C18) | KILLS |
| Dimethyl Benzyl Ammonium Chloride | 0.085% | MRSA, FLU PARVO, HIV |
| n-Alkyl (68% C12, 32% C14) | | |
| DimethylEthylbenzyl Ammonium Chloride | e0.085% | EPA Reg. No. 71700-2EPA |
| OTHER INGREDIENTS | 99.630 % | Est. No. 085984-MI-002 |
| TOTAL | 100% | Net Contents: 1 Gallon |

KEEP OUT OF REACH OF CHILDREN

APPROVED FOR HVAC

DISTRIBUTED BY: GLOBAL ENVIRONMENTAL RESTORATION, INC. P.O. BOX 667 | CARENCRO, LA 70520 | 877.236.4710

Kills 99.9% of Germs • Kills Bacteria in 60 seconds

Deodorize with SNIPER^{*}: Eliminate odors at the source – eliminate odor in shoes, furniture, mattresses. curtains / drapes, carpets, rugs, sports equipment, helmets, gloves, body armor, and vehicles. (Always check for fabric color fastness in an inconspicuous area.) Spray SNIPER® at full strength with spray bottle or electric / pump atomization sprayer, thoroughly wetting surfaces and let air dry for residual deodorization action. SN PER[®] must contact the source or cause of the odor to be effective. For urine and / or pet odors in carpets, thoroughly wet the carpet with **SNIPER**[®], or saturate to the pad[ding] for complete deodorization. (For concerns of color fastness on carpets / fabrics in deodorizing applications use at a 5 to 1 dilution)

IDEAL FOR ELIMINATING ODORS: Strong Cat Odors / Pet Odors, Animal Kennels, barn stalls, Urine and other Waste Odors, Strong Ammonia Odors, strong sulfur & formaldehyde odors, strong smoke odors caused by fire, tobacco, and other sources and odors from mold and mildew. SN PER® is perfect for eliminating the toughest odors in the air, is fragrance free and perfect to use in your indoor environment!

Deodorize HVAC System Ductwork (non-pathogenic organisms only): Spray product into system intake vents while system fan is running. Allow enough spray time for product to contact air duct system surfaces, repeat application if necessary.

Non-Pesticidal Allergen Removal: Destroy and eliminate non-living allergens such as: Cockroach matter • Dust mite matter Pet Dander

Reduce and remove allergens (Peel Back Label to see Directions to remove Allergens)

No Rinse Required • Ready to use spray

FOR ADDITIONAL INFORMATION ON SPECIFIC APPLICATIONS WITH SNIPER[®] Call 877-236-4710.

SNIPER[®] was specifically engineered for the disinfection needs associated with the high demands of industrial uses, Healthcare facility uses, as well as everyday applications in the home.

provides hospital disinfection, multi-surface cleaning, and odor elimination.

SNIPER[®] disinfects as it cleans - Tough on germs, easy on surfaces!

Directions for use: It is a violation of Federal Law to use this product in a manner inconsistent with its labeling. Gently shake 2-3 times prior to use

Pre-Cleaning Instructions: Remove gross fifth and heavy soil by cleaning. Thoroughly wet surfaces by spray, sponge, mop, or immersion with SNIPER* on to soiled surfaces then thoroughly clean and wipe away gross filth with sponge or cloth.

Disinfect Hard Non-Porous Surfaces: For disinfection of pre-cleaned hard non-porous surfaces such as glass, plastic, painted or finished wood, chrome, stainless steel, aluminum, polyurethane coated hardwood floors, plazed ceramic tile, sealed concrete and linoleum floors, etc. Spray SNIPER* at full strength, at a distance of 6-8 inches from surfaces while wetting surfaces thoroughly. Allow surfaces to remain visibly wet for 5 min for disinfection of Gram-Negative bacteria. Gram-Positive bacteria. Staphylococcus aureus ATCC 6538 (Staph). Salmonella enterica ATCC 10708. Pseudomonas aeruginosa ATCC 15442. Methicillin Resistant Stanbylococcus aureus (MRSA) ATCC 33591, Vancomycin Resistant Enterococcus faecalis (VRE) ATCC 51299, Allow surfaces to remain wet for 10 minutes for virus inactivation of Swine Influenza virus, Type A (H1N1) ATCC VR-333 and Canine Parvovinus ATCC VR-953. SNIPER® KULS HIV-1 and HRV ON SURFACES PREVIOUSLY SOULED WITH BLOOD / BODY FLUIDS. In healthcare or other settings where a likelihood of surfaces / objects to be soiled with blood and / or bodily fluids with the optential of the transmission of Human Immunodeficiency Virus Type 1 (HIV-1) (associated with AIDS) and Human Hepatitis B Virus follow the instructions for cleaning and decontamination of surfaces.

Personal Protection: Use disposable latex gloves, gowns, masks or eye covering when handling items soiled with blood or bodily fluids.

Cleaning Procedures: Blood and other bodily fluids must be thorouphly cleaned from surfaces and objects before application of this product.

Disposal of infectious materials:

Blood and other hodily fluids must be autoclaved and disposed of according to Federal. State, and local regulations for infectious waste disposal.

Contact Time:

Allow surfaces to remain visibly wet for 5 minutes for the inactivation of Human Immunodeficiency Virus Type-1 (HIV-1)* and Human Hepatitis B Virus (HBV)*

To Disinfect Food Processing Premises: floors, walls and storage areas, hold container six to eight inches from the surface to be treated and spray area until it is covered with the solution Allow this product to penetrate and remain wet for required contact times: (5 minutes for Bacteria See contact list - 10 min for Virus inactivation See list above) Heavily soiled areas must be pre-cleaned before using this product. Food products and packaging materials must be removed or carefully protected prior to using this product.

Sanitization:

Hard Surface Sanitization No Rinse Required: 60 sec contact time Staphylococcus aureus (ATCC 6538) Salmonella enterica serovar tvohi (ATCC 6539) To Sanitize Non-food Contact Hard Non-porous Surfaces: Stanbylococcus aureus (ATCC 6538) and Salmonella enterica servor typic (ATCC 6539) sanitization of food contact surfaces. Mix 1 part product to 6 parts tap water. For plassware, utensils, conkware, and dishware; Scrape and pre-wash, then wash with a good detergent. Rinse with potable water, then sanitize by immersion in product for 1 minute (or longer if specified by government sanitary code). Place on a rack or drain board to air dry. Do not rinse or wice. Food Contact Immobile Surfaces: (food processing equipment, counter tops, tables, appliances) Remove all gross food particles and soil by cleaning and rinse with potable water. Apply product by wetting thoroughly and let stand for 1 minute (or longer if specified by government sanitary code). Let surfaces drain and air dry. Do not rinse or wipe.

Fundus Treatment Directions for Use: To Eliminate Fungus: SNIPER* kills Triochphyton mentagrophytes ATCC 9533 fungus on hard-non porous surfaces. Treat surfaces contaminated with funnus thoroughly with SMPER^(B) and remove visible growth from surface. To disinfect, spray to thoroughly wet pre-cleaned surface and allow surface to remain wet for 10 minutes for Triochphyton mentagrouphytes ATCC. 9533, SNIPER® can be used in all disaster recovery, such as fire and smoke damage or flood and water damage. Disaster Recovery Directions of Use: After cleaning surfaces of all organic matter (dust, mud, debris, etc.) spray SNiPER* on all surfaces for removal of smoke from fire damage. Floodwaters can bring concern of bacteria. Use SNiPER* after floodwaters recede and after clean and drying is complete. (Follow directions for use for disinfection applications) Directions to Remove Allergens: To clean and reduce specified allergens spray wait 1 minute, and wipe excess. Allow to air dry. If streaking is observed, wipe with a clean, damp cloth or paper

ENVIRONMENTAL HAZARDS

Do not discharge effluent containing this product into lakes, streams, ponds, estuaries, oceans or other water unless in accordance with the requirements of a National Pollution Discharge Elimination System (NPDES) permit and the permitting authority has been notified in writing prior to the discharge. Do not discharge effluent containing this product to sewer systems without preciously notifying the local sewage treatment plant authority. For ouidance contact your State Water Board or Regional office of the EPA.

HVAC Directions for Use:

FOR ANTIMICRIOBIAL CONTROL IN HVAC SYSTEMS AND AIR DUCTS (INCLUDING ODOR CAUSING BACTERIA). IT IS A VIOLATION OF FEDERAL LAW TO USE THIS PRODUCT IN A MANNER INCONSISTENT WITH ITS LABELING THE PERSON APPLYING THIS PRODUCT IS RESPONSIBLE FOR FOLLOWING THESE DIRECTIONS LINDER BOTH STATE AND FEDERAL LAWS.

If you need help in understanding any part of these instructions or have additional questions after reading these instructions, DO NOT APPLY THIS PRODUCT until you have received the answers for all of your questions.

Inspection: Prior to inspecting, cleaning, treating, repairing or otherwise working on the HVAC or duct section, the HVAC system should be turned off or the section under repair physically isolated from sections active use. Prior to any application of PRODUCT the system must be inspected for cleanliness and mechanical condition. When initiation any measures to renair, clean or treat HVAC system components or air ducts, industry frequency schedules for ducts and other system components. More information on NADCA standards can be obtained from the NADCA web site at www.nadca.com.

Cleanliness Inspection: According to NADCA Standards, HVAC system cleaning must be performed when any of the following conditions are found in the cleanliness inspection. If any of these deficiencies are found during inspection, cleaning in accordance with industry standards must be performed prior to the application of PRODUCT. At a minimum, these standards require removing all loose soil and debris with a HEPA filter equipmed vacuum damaging fumes.

Contamination: HVAC systems should be operated in a clean condition. If significant accumulations of contaminants or debris are visually observed within the HVAC system, then cleaning is necessary, Likewise, if evidence of microbial growth is visually observed or confirmed by analytical methods, then cleaning is required. If the HVAC system discharges visible particulate into the occupied space, or a significant contribution of airborne particles from the HVAC system into the indoor ambient air is confirmed, then cleaning is necessary. Heat exchange coils, cooling coils, air flow control devices, filtration devices, and air-handling equipment determined to have restrictions, blockages, or contamination deposits that may cause system performance inefficiencies, air flow depradation, or that may significantly affect the design intent of the HVAC system, require cleaning. Drain page must be free from slime and sludge or other contamination. Badly rusted or corroded drain pans must either be renaired or replaced.

Fans and Fan Housings: Must be free from accumulations of microbial prowth and particulate matter.

Filters: Must be in good condition and cleaned or replaced as needed to avoid exceeding the allowable pressure drop for the equipment. If you need help in understanding existing industry standards, consult a qualified professional or contact Customer Service at 1-877-236-4710 for quidance and further direction or consult the information at www.epa.gov (search on "HVAC Systems" or "air ducts"). In addition, the following association and www.smacna.org.

Mechanical Inspection: PRODUCT must be used only on HWAC system components and air ducts in sound mechanical condition as defined in 22.1 and 2.22 (below). The HWAC system components must be designed and installed in conformance with industry standards and quidelines. Prior to using the Product, inspect the HVAC system and ducts and assure that they are in sound mechanical condition. The following general quidelines. supplemented by industry standards from SMACNA, NAIMA, ASHRAE, ACCA and other organizations, must be followed:

Air Leaks and Mechanical Defects: The equipment housing, cabinets and ducts must be free from air leaks and other mechanical defects. Air leaks will promote condensation of water that causes microbial prowth and will lead to failure of PRODUCT to protect the system adequately.

Design and Installation: ASHRAE. SMACNA, NAIMA and other industry organizations have established quidelines and standards for the design and installation of HVAC and duct systems. You should determine that the system system include: Improper size of system or component: The system and all components must be sized to achieve correct airflow and be of the proper capacity for the load. When air-handling equipment is changed or new inlets or outlets added, the size of all components in the system should be recalculated and replacements made as needed.

Physical Damage: Crushed or physically damaged equipment may leak or fail to perform as designed. Deformed air ducts will restrict airflow and may leak (especially at joint areas). Damaged equipment must be repaired or exchange surfaces.

Loose. Damaged. Friable or Missing Insulation: Insulation is important in preventing maisture condensation and subsequent prowth of bacteria and other organisms. If insulation (either interior or exterior) is damaged. mission or not properly fastened it must be renaized or replaced or the associated duct sections replaced. Air handler, mixing, and VAV hox housings are also normally insulated and this insulation should be checked for damage in a like manner, Removed components that are contaminated with bacteria and other microbial growth may spread contamination while being removed from the building. To grevent this, smaller items should be glaced in glastic Service at 1-877-236-4710 for ouidance on the appropriate disinfectant to use for treatment.

General Directions for PRODUCT Usage: PRODUCT effectively controls by inhibiting growth of odor causing bacteria, fungi, and other odor, stain or damage causing organisms in HVAC system components and air ducts in residential, commercial, institutional, and industrial buildings, PRODUCT also eliminates odors associated with bacteria, smoke, animals, cooking, spoilage, musty and other odors and removes odor-causing organisms when used or bleach materials or fabrics and will not harm or damage HVAC system components.

PRODUCT is formulated for use in all kinds of HVAC components and air ducts including:

Furmaces. Air Handlers. Packaoed units including Rooftops and Packaged Terminal Air Conditioner (PTAC) units, Fan coil units, Air distribution, components such as air handlers, mixing boxes, transfer boxes, transitions, and turning vanes, dampers, fans and fan housings, and associated components; Condensate drain pans, Unlined sheet metal ducts. Air supply and return ducts and plenums fabricated with plywood. QSB or other wood like material; Flexible air ducts fabricated of metal or plastic, Humidifiers, Dehumidifiers; both Desiccant and Refrigerated, Registers, Grills and other air intake and discharge devices Follow the directions below for the specific type of duct or component being treated. It is vital that the following directions be carefully read and understood prior to using the Product. If you have any questions, need further There is no need to have occupants leave the building during application. information, require clarification, or do not understand any of the directions, call Customer Service at 1-877-236-4710 prior to use.

HVAC Application Instructions: Wet the surfaces with the spray, giving special attention to cracks and crevices. [Product] will not stain any materials not stained by water] we suggest testing for compatibility on surface of concern first. Allow ten to twenty minutes for drying. No rinsing or wiping is required. Following the elapsed drying time it is best gractice to gurge the system, by increasing the negative pressure through the outdoor exhaust or negative air machine or by turning on the vacuum used to preclean the HVAC system, while removing the duct openings seals. This will minimize the release of scent into the spaces served by the system.

Application Equipment and Devices: Refer to the orecautionary statements for the Personal Protective Clothing and other special instructions that must be followed.

Sprav Applicators:

Sorav application is preferred on large surfaces that are easily accessible (such asplenums, coil assemblies, the interior of cabinets, housings with removable access ganels, and in long runs of large diameter ducts). The sorav equipment chosen should provide a consistent fine (1-300 micron) particle size and uniform spray pattern. Powered medium pressure sprayers are preferred. However, airless sprayers are suitable. Where airless sprayers are used, the most satisfactory spray pattern will be achieved using a 0.01 1" spray tip. For other brands and options contact Customer Service at 1-877-236-4710. Pump up garden type sprayers can be used but care must be taken to maintain maximum pressure by pumping frequently and the soray nozzle must be adjusted for the finest soray pattern possible. During application achieve complete uniform coverage. Avoid excessive wetting and do not allow the soray to run or pool. Automated Atomizing or Spray System: There are a number of automated soravino systems on the market including those that are carried by a "robot" through air ducts. These may provide an excellent option for application of PRODUCT in parts of air ducts that are difficul standards from the American Society of Heating and Refringeration Engineers (ASHRAE). Hational Ar Duct Cleaners Association (HADA) and other organizations must be followed. HVAC to access if they organize to ac systems should be routinely inspected for cleanliness by visual means. The HADCA Standard, Assessment, Cleaning and Restoration of WAC Systems (AAC 2002 or the latest revision), provides minimum recommended inspection Service at 1-877-256-4710 reparting a specific drive should you have questions. Brush, Mop or Wipe Application: Brush, Mop or Wipe oenerally more labor intensive than other methods and are normally used only when specifications require. These methods are suitable only for smooth uniform surfaces. Do not use on porous or non-uniform surfaces. If in doubt about a given surface, contact Customer Service at 1-877-236-4710 before proceeding. When using brush or mog application, tools and materials used should be reserved only for application of PRODUCT, kept clean and protected between uses and replaced when worn or visibly solied, Natural fiber brushes are preferred although any quality brush is acceptable. Moos should be of the types that leave minimal lint behind. Micro-fiber or other non-linting cloths are preferable. Where other types are the types that have a solid clother and the types are the types and the types are the type are the types ar cleaner and comolete cleaning of soil from all heat exchance surfaces using a special cleaner formulated so as to clean such soils effectively vet not damage heat exchance surfaces her o rotentially cluster with the value of t require entering the component or air ducts. In such cases, application must start from the point most distant from the point of entry. The applicator will then work from that point back to the entry point covering a 3-foot length of duct at time. Apoly to the top of the area to be treated first, followed by the sides then the floor, Overlap applications to assure complete coverage. Cover completely while avoiding runs or pooling. Application Techniques: PRODUCT must be applied eventy to surfaces that are being treated. Even and uniform application is essential for satisfactory results. The procedures, equipment and techniques described below have been tested and provide the desired results. Other procedures equipment or techniques may also achieve satisfactory results but should not be used without discussing the specific situation and equipment with a Customer Service Representative who can be reached toll free at 1-877-236-4710.

Application from Exterior of the HVAC System or Air Duct:

PRODUCT may be sprayed into existing access openings where these provide adequate access. Normally these consist of removable panels or access doors. Completely cover all nonelectrical components until they are thoroughly and uniformly covered using hand or powered spray equipment. This is the technique of choice for large penthouse or built up air handlers and other components with access panels or doors. When applying to ductwork, spray into openings at a minimum society Internet sites should be consulted for information on standards and quidelines they have developed: ACCA - www.naima.org SMACHA - www.naima.org SMACHA - www.naima.org SMACHA - of every 8 feet Existing supply openings can be used where they provide a clear view of the surfaces being sprayed so that uniform application can be achieved. However, additional penetrations will have to be made, as needed, so enough openings will be available to achieve total and uniform coverage. Spray application is not an acceptable technique where openings are greater than 8 feet apart, additional openings cannot be made and properly sealed, and/or the duct geometry does not allow for uniform coverage. In such cases, application from within the HVAC system is necessary (see 3.3.2 below). Application from Within the HVAC System: When PRODUCT cannot be sprayed into openings at intervals throughout the HVAC or duct system, you must gain entry into the system and spray the Product onto interior surfaces until they are thoroughly and uniformly covered using hand or powered spray equipment. This is the most frequently used technique and is the technique of choice for air handlers,other components with access panels or doors and large diameter (generally 20" x 20" minimum) ducts where direct access can be gained to surfaces being treated. Some protection is provided for drain pans by excess PRODUCT that runs off of cooling coils when they are treated. Spraying PRODUCT, onto the surfaces of the pan or pouring into the drain pan until the bottom of the pan is uniformly wetted, can provide additional protection. Before treating the drain pan, check to determine that the drain line is clear and free running and that the drain pan is clean and free of loose corrosion. Replace badly deteriorated pans. Drain pans that do not drain completely and retain water may experience microbial growth even when treated. Level drain pans and otherwise adjust them so water completely drains from them. Fans and Fan Housings: Fans create air turbulence, which can lead to condensation of water that supports bacterial and other growth. As a result, fan blade and blower wheel surfaces as well as associated housings are especially prone to fouling from both microbial growth and soil accumulation. It may be necessary to partially o components you wish to treat conform to industry practice. If you are not knowledgeable of industry guidelines and standards, consult a qualified professional or contact Quatomer Service at 1-377-238-4110 for assistance. In some situations, the inspection may reveal that a communit of the HV3C or duct system is badly damaged or in such non-rentation builds on over time. This accumulated material must be annual of water meseries. In these situations — of the annual of water meseries. In these situations — of the annual of water meseries. In these situations and/or minimizer and a deluminifiers and deluminifiers are often sites enceded on the transmission builds on over time. This accumulated material must be annual of water meseries. the status and to space and the status and the stat proper maintenance and cleaning procedure. Rate of Application: The recommended rate of application for PRODUCT varies depending on the surface being treated. Users of this Product must carefully follow the rate of application instruction: provided below: Bare Metal and Flexible Ducts: Apply until surface is evenly wet. Coverage 1,000 ft2 per gallon. Spray coverage 500 ft2 per gallon. If the above application rates result in surface runoff or liquid pooling on the bottom of the replaced or if there is extensive dismance, the entire system should bereplaced. Badly corroded melal components: Including duct sections, housings and eabinets, coll assemblies, drain pans, fans and their housings and teat drain nan so as to nenetrate the coil assembly to the preatest possible denth. Semi Porous Surfaces such as Concrete or Plaster: Anoly until surface is evenly wet. Coverane 500 ft? per pallon. Wine not recommended. Spray coverane 250-ft? per gallon. PRODUCT must penetrate into surface crevices and irregularities or it will not be effective. Inspect and assure that penetration is satisfactory. It may be helpful to apply half of the quantity needed for full coverage spraying from side to side then repeat the application moving the spray from top to bottom. Frequency of Application: Normally, infrequent application (every 3 months for HVAC Systems and every 6 months to every two years for air ducts) will provide effective control. Some critical applications such as HVAC and duct systems serving critical health care spaces or clean rooms where it is essential to minimize the generation of particulate matter that may be released as a by Product of microbia bags that should then be sealed before being removed. Larger items that cannot be safely packaged should be treated before being moved through occupied spaces. An appropriately labeled disinfectant can be used during growth may require more frequent treatment. Do not apply more often than monthly and then only if there is evidence of re-proved. This Product must only be used in those cases where visible microbial nowth has been detected in the system treatment. Care must be used during treatment to assure that fumes from the agent being used are not released into occupied spaces. Products used should be used according to their label directions. Please contact Customer and then only after removing that growth and identifying and correcting the conditions that led to that growth. Prior to reapplication in such cases, investigate to determine the cause of re-growth and correct that problem prior to re-application Before embarking on a program of frequent application (more frequent than every three months) contact Customer Service at 1-877-236-4710 to discuss the specific application and situation. Also make sure the reoccurrence of microbial growth does not have another cause such as persistently high humidity, standing water or hidden leaks. Prior to reapplication, the interior of the ducts and other surfaces must be inspected and found to be free of accumulated soil. If soil o growth is found, the cause should be determined and corrected and then the ducts cleaned in accordance with accepted industry practice. If microbial growth persists in air ducts following application re-inspect for duct leaks, carryover of as part of such a comprehensive preventative maintenance program in HM2 systems and air ducts. PRODUCT is a bacteristat, thingister, and bedoutizer for use in residential, commercial and industrial settinos. It will not stain water from cooling coils or humidifiers and other sources of moisture promoting urowth. Eliminate such sources of moisture before retreating, Returning the System to Operation following Acolication: Evolutionent beino treated and the fans an blowers in the section of duct being treated must be turned off during application of PRODUCT. If the system cannot be shut down, the section of the system being treated must be isolated until treatment is complete. This will prevent the spray from being blown away from the surface that is being treated. Do not attempt to use the system fan or blower to carry PRODUCT to the surfaces within system. Such a practice will not result in uniform application of the Product to the surfaces being treated and will lead to ineffective control. Do not attempt this. The system can be returned to full operation as soon as treatment is completed or at any time following completion of treatment. PRODUCT will dry on surface within 15 minutes following application. Extended drying time does not have an impact on effectiveness of treatment. PRODUCT should not be rinsed off following application so it will continue to inhibit the growth of microorganisms on treate surfaces. When the above directions are followed properly, there will not be significant concentrations of Product released to the spaces served by a system being treated.